



IBM ThinkPad T30 Battery Replacement

A guide showing how to remove and replace the battery from the IBM ThinkPad T30.

Written By: Allie Knauer



INTRODUCTION

Use this guide to remove your battery.



TOOLS:

- [Fingers](#) (1)
-

Step 1 — Battery



- i** Make sure the ThinkPad is off and the power supply is unplugged.
- Flip the ThinkPad upside down with the bottom facing you.
 - Slide the latch on the underside of the ThinkPad to the right into the unlock position.
 - While holding the latch in the unlock position, lift the battery out with your other hand.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-01 02:10:31 AM.